


Dynamic Measurements with Static Coils and Hall Probes

F.Patru; A.Akhmetov; L.Bottura; P.Pugnat; L.Walckiers for the LHC-MTA group

Summary

- Loss & Field advance
- Principle of measurement
- Different methods of measurement
- Acquisition systems
- FA with PDI: Results
- Comparison between methods

Loss & Field advance




Interstrand & interfilaments coupling currents depends on:


- the cable geometry
- the contact resistance between the strands
- the current ramp rate (linearly)

Loss & Field advance


- Interstrand & interfilaments coupling currents
- ⇒ Losses : energy dissipated in the magnet
- ⇒ Field advance : distortion of the magnetic field due to eddy current
- Measurement at different current ramp rates
- ⇒ Loss & FA factors
- ⇒ resistive contact value (Rc) of cables comparison of Rc get with different methods


Loss: Principle of measurement







$$V_{magnet} = L * \frac{dI}{dt} + R_{connexions} * I + V_0$$








FA: Principle of measurement












Different methods of measurement

Measure	Pick-up	Measuring instrument	Measurand
Loss	Voltage taps	DVM	Vmagnet
FA	Fixed coils (induction)	DVM	Vcoil
FA	Hall probes	DVM	V HP
FA	Fixed coils (induction)	PDI	Δψ≡∫ Vcoil*dt

Loss & FA: Acquisition system


→ Using digital voltmeters KEITHLEYS (DVM)

External trigger





FA: New Acquisition system


→ Using precision digital integrators (PDI)





analog current signal











Comparison of the methods

Loss:	FA:	FA:	FA:		
VT + DVM	Coils +DVM	HP + DVM	Coils + PDI		
© Integral	© Integral	⊗ Local (average on	© Integral		
	(on all the magnet or	many sensors ())	(on all the magnet or		
	on each sector)		on each sector)		
		©Reproducibility(?)			
©Magnet symmetry	© Only integral	© To study local	© Only integral		
between apertures	value of FA needed	aspects	value of FA needed		
	of accelerator	(Periodic Magnetic	of accelerator		
© Energy dissipated	control	Field Pattern,	control		
$W=1/2*L*I^2$		transient effect)			
\odot Integration Vo \Rightarrow	drift on B(t)	© No integration	© Directly		
compensation by a linear regression		(B=k*V)	integrated;		
			data treatment easier		
⊗ DVM : Dead time -> accurate compensation					
⊗ DVM : time depe	endant voltage offset	© less susceptible:			
		short measurement			
© Current correction: synchronisation of field & current read-out					
New mecanism for synchronous current acquisition?					

Conclusion

- 3 kinds of measurements:
 - Loss : Energy aspect
 - FA with coils : integral value needed for the accelerator performance assessment and control
 - FA with Hall Probes : local aspect
- 2 acquisition systems :
 - Precision digital integrators : coils
 - Digital voltmeters : voltage taps, Hall probes